



HOW TO WINTERIZE YOUR FLOOR SYSTEM





HOW TO WINTERIZE YOUR FLOOR SYSTEM

1

STEP 1

Turn off all power in the breaker box location at the pool equipment.

2

STEP 2

Identify if pool equipment is above or below pool. If below, turn red or blue shut off valves.

3

STEP 3

Unscrew black handle on valve pod.

4

STEP 4

Remove silver band from valve pod.

5

STEP 5

Lift open tinted lid (do not lose the lids gasket).


STEP 1

Turn off all breakers at pool equipment.



STEP 2

Identify if your pool equipment is below or above your pool's water level.



STEP 2

If your pool equipment is below your pool's water level turn all **LARGE** red ball valves off before removing any drain plugs from your equipment.



STEP 3

Unscrew black handle on valve pod



STEP 4

Remove silver band from valve pod



STEP 5

Lift open tinted lid (do not lose the lids gasket)





WINTERIZING YOUR FLOOR SYSTEM